

AN2700 Ethylene Oxide Meter

EtO Sterilization Accessories

Handheld Monitor

- ▶ Compact, lightweight, durable
- ▶ High reliability
- ▶ Fits in a shirt pocket or on the belt
- ▶ LCD display with battery status indicator
- ▶ Fixed system installation available
- ▶ Audible alarm; adjustable between 0-100 ppm

The AN2700 Ethylene Oxide Meter is a pocket sized instrument that can measure the ethylene oxide concentration in air in the 0-100 ppm range. It is used in hospitals, medical product manufacturing and in the chemical processing industry. Personnel monitoring for OSHA compliance and area monitoring are easy and low cost.

The instrument has a LCD display giving concentrations in ppm, a low battery indicator and an audible alarm that can be set at any level in range of the sensor. There is a clip that permits the instrument to be worn on the belt or in a pocket. The instrument can easily be checked for calibration, with optional equipment, at the beginning of a work shift. The low cost 9 volt battery has an operational life in excess of 1000 hours. Operation on AC power is an available option.

OPERATION

The sensing element is an electrochemical cell. The working electrode of the cell is maintained at a fixed potential versus a reference electrode. The electrode is a gas diffusion type in which Ethylene Oxide diffusing through a porous membrane is electrochemically oxidized. A porous Teflon membrane serves as a physical support for the electrode structure and as a diffusion barrier. An active catalyst is bonded to the membrane. The current output is governed by Faraday's Law and mass transport of Ethylene Oxide to the reaction surface. The response is linear with the concentration of Ethylene Oxide in the air. The design advantages include simplicity in construction, a large output signal, long life, and high reliability.



PERFORMANCE DATA

Sensor Technology	Electrochemical
Range	0-100 ppm
Minimum Detectable	0.1 ppm
Response Time	
1 ppm (TLV)	<5 sec.
90% peak	<140 sec.
Recovery Time	
10% peak	<270 sec.
Repeatability	+/-0.2 ppm
Linearity	R.C. = 0.98
Zero Drift	<0.1 ppm/day
Sensitivity Draft	<+/-2%/day
Operating Temperature	20-35°C
Alarm	Audible
Alarm Settings	0-100 ppm
Dimensions	H x D x W 4.75 x 2.5 x 1.5 inches
Weight	170 gms
Power Source	9V alkaline battery
Sensor Life	2+ years

INTERFERENCES

Concentrations of gases sometimes encountered in facilities where Ethylene oxide is used are given below. The concentrations are those required to indicate 1 ppm Ethylene oxide.

Gas	Concentration,ppm
Acetone	109
Isopropanol	6
Freon	no response
Carbon Dioxide	no response

SAFETY

The instrument is an extremely safe device when the recommended low cost, low discharge rate 9 volt carbon cell is used. Under most circumstances there is insufficient energy to ignite a combustible gas mixture.

The unit is being certified by the Canadian Standards Association as a Division II device.

Applications

- Measure personal exposure for OSHA compliance testing.
- Measure short term exposures during Ethylene oxide tank charges.
- Measure residual Ethylene oxide in aerated materials.
- Detection of Ethylene oxide leaks.
- Fixed system installation continuously monitoring a given area.

ORDERING INFORMATION

For additional information contact us at:



Andersen Products, Inc.
3202 Caroline Dr.
Haw River, NC 27258 USA
800-523-1276
Fax: 336-376-8153

Distributed by:
 **ANDERSEN PRODUCTS**
sterilization redefined

www.anpro.com
Andersen Products, Inc.
Health Science Park • 3202 Caroline Drive
Haw River, NC 27258-9564 USA
800-523-1276 • fax 336-376-8153

www.andcal.com
H. W. Andersen Products of California, Inc.
Health Science Park • 3151 Caroline Drive
Haw River, NC 27258-9789 USA
800-524-3455 • fax 336-376-3088

Distributed in Europe by:
H.W Andersen Products, Ltd.
Davy Road • Clacton-on-Sea
Essex CO15 4XA UK
1255-428-328

P/N4450_100606